



# Selection guide

## AC measurement and monitoring system

### DIRIS Digiware AC

Build your own AC measurement system



#### Find the best DIRIS Digiware configuration




The Socomec Meter Selector is your digital assistant, helping you find the best DIRIS Digiware configuration for your power monitoring projects, and all in just a few clicks!

1. Fill in information regarding your project.
2. Download the system diagram and bill of material.
3. All your projects are archived in your personal account.

## Control and power supply interface

Application	Centralisation and display of data				Data centralisation	Repeater
	D-50	D-70	M-50	M-70	C-31	C-32
<b>DIRIS Digiware</b>						
<b>Function</b>						
Centralising measurement points	•	•	•	•	•	
High-resolution LCD display (configuration, selection and viewing of circuits)	•	•				
Repeater						•
<b>Power supply</b>						
24 VDC	•	•	•	•	•	•
<b>Communication</b>						
RS485 Modbus	Input/Output	Input/Output	Input/Output	Input/Output	Output	
Digiware bus	•	•	•	•	•	•
Bluetooth	•	•	•	•		
Ethernet	Modbus TCP BACnet IP SNMP	Modbus TCP BACnet IP SNMP	Modbus TCP BACnet IP SNMP	Modbus TCP BACnet IP SNMP		
Embedded web server	WEB-CONFIG	WEBVIEW-M	WEB-CONFIG	WEBVIEW-M		

## Voltage acquisition module

Application	Metering	Analysis
	U-10	U-30
<b>DIRIS Digiware U</b>		
<b>Multi-measurement</b>		
U12, U23, U31, V1, V2, V3, f	•	•
U system, V system,		•
Ph/N unbalance		•
Ph/Ph unbalance		•
<b>Quality analysis</b>		
THDv1, THDv2, THDv3, THDu12, THDu23, THDu31		•
Crest factor V1, V2, V3, U12, U23, U31		•
Individual harmonics U & V (up to 63rd)		•
Voltage dips, interruptions and overvoltages (EN 50160)		•
<b>Alarms</b>		
Thresholds and combinations		•
<b>Trends</b>		
Average values		•
<b>Format</b>		
Width/number of modules	18 mm / 1	18 mm / 1

# Selection guide

## AC measurement and monitoring system

### DIRIS Digiware AC

#### Current acquisition modules

Application	Metering			Analysis		Monitoring	Analysis		Metering		
<b>DIRIS Digiware Iac</b>	<b>I-30</b>	<b>I-30MID</b>	<b>I-31</b>	<b>I-35</b>	<b>I-35MID</b>	<b>I-43</b>	<b>I-45</b>	<b>I-60</b>	<b>I-60MID</b>	<b>I-61</b>	<b>I-61MID</b>
Number of current inputs	3	3	3	3	3	4	4	6	6	6	6
Metering											
$\pm \text{kWh}$ , $\pm \text{kVAh}$ , $\text{kVAh}$	•	•	•	•	•	•	•	•	•	•	•
Load curves			•	•	•		•			•	•
Multi-tariff			•	•	•		•			•	•
MID		•			•			•			•
Multi-measurement											
I1, I2, I3, In, $\Sigma P$ , $\Sigma Q$ , $\Sigma S$ , $\Sigma \text{PF}$	•	•	•	•	•	•	•	•	•	•	•
P, Q, S, PF per phase			•	•	•	•	•			•	•
Predictive power				•	•		•				
Current unbalance (Inba, Idir, linv, Ihom, Inb)				•	•		•				
Phi, cos Phi, tan Phi					•	•	•				
Quality											
THDi1, THDi2, THDi3, THDin				•	•	•	•				
Individual harmonics I (up to 63rd)				•	•		•				
Crest factors I1, I2, I3, In				•	•		•				
Overcurrents				•	•		•				
Alarms											
Thresholds and combinations			○	•	•		•		•	•	•
Inputs/outputs						2/2	2/2				
Trends											
Average values				•	•		•				
Format											
Width/number of modules	18 mm / 1	18 mm / 1	18 mm / 1	18 mm / 1	18 mm / 1	27 mm / 1.5	27 mm / 1.5	36 mm / 2	36 mm / 2	36 mm / 2	36 mm / 2

○: only for total power (P,Q,S).

To comply with the MID directive, the DIRIS Digiware system must have a D-50/D-70 display.

#### Input/output modules

Application	Metering / monitoring / remote control	
<b>DIRIS Digiware IO</b>	<b>IO-10</b>	<b>IO-20</b>
Number of digital inputs/outputs	4/2	
Number of analogue inputs		2
Format		
Width/number of modules	18 mm / 1	18 mm / 1

## Current acquisition module with built-in sensors

Application	Metering	Analysis	
<b>DIRIS Digiware S</b>	<b>S-130</b>	<b>S-130MID</b>	<b>S-135</b>
Number of current inputs	3	3	3
Basic current $I_b$	10 A	10 A	10 A
Maximum current $I_{max}$	63 A	63 A	63 A
Load type accepted	1P + N 2P / 2P + N 3P / 3P + N	1P + N 2P / 2P + N 3P / 3P + N	1P + N 2P / 2P + N 3P / 3P + N
Metering			
$\pm \text{kWh}, \pm \text{kVArh}, \text{kVAh}$	•	•	•
Multi-tariff (max 8)			•
Load curves			•
MID		•	•
Multi-measurement			
$I_1, I_2, I_3, In, \Sigma P, \Sigma Q, \Sigma S, \Sigma PF$	•	•	•
P, Q, S, PF per phase			•
Predictive power			•
Current unbalance (Inba, Inb, Idir, Inv, Ihom)			•
Phi, cos Phi, tan Phi			•
Quality			
THDi1, THDi2, THDi3, THDin			•
Individual harmonics I (up to 63rd)			•
Crest factors U, V, I			•
K factor			•
Overcurrents			•
Alarms			
Thresholds and combinations			•
Connection errors			•
Protection alarms	•	•	•
Trends			
Average values			•
Format			
Width	54 mm	54 mm	54 mm
			54 mm

To comply with the MID directive, the DIRIS Digiware system must have a D-50/D-70 display.

# Selection guide


## AC measurement and monitoring system

### DIRIS Digiware AC


Multi-circuit measurement modules with built-in sensors for power distribution units (PDU)

<b>DIRIS Digiware BCM</b>	<b>BCM-1818</b>	<b>BCM-1818VM</b>	<b>BCM-2119</b>	<b>BCM-2119VM</b>	<b>BCM-2125</b>	<b>BCM-2125VM</b>
Number of current inputs	18 + 3x RJ12	18 + 3x RJ12	21 + 3x RJ12			
Nominal current / Maximum current Imax	32...63A/80A	32...63A/80A	32...63A/80A	32...63A/80A	40...100A/120A	40...100A/120A
Load type accepted	1P+N 2P 2P+N 3P 3P+N	1P+N 2P 2P+N 3P 3P+N	1P+N 2P 2P+N 3P 3P+N	1P+N 2P 2P+N 3P 3P+N	1P+N 2P 2P+N 3P 3P+N	1P+N 2P 2P+N 3P 3P+N
<b>Metering</b>						
±kWh, ±kVarh, kWh	•	•	•	•	•	•
Multi-tariff (max. 8)	•	•	•	•	•	•
Load curves / Demand profiles	•	•	•	•	•	•
<b>Multi-measurement</b>						
I1, I2, I3, In, $\sum P$ , $\sum S$ , $\sum PF$	•	•	•	•	•	•
P, Q, S, FP per phase	•	•	•	•	•	•
Predictive power	•	•	•	•	•	•
Current unbalance (Inba, Idir, linv, lhom, Inb)	•	•	•	•	•	•
Phi, cos Phi, tan Phi	•	•	•	•	•	•
<b>Power quality</b>						
THDi1, THDl2, THDi3, THDin, THD Isys	•	•	•	•	•	•
Individual harmonics I (up to 63rd)	•	•	•	•	•	•
Crest factor I1, I2, I3	•	•	•	•	•	•
Overcurrent	•	•	•	•	•	•
<b>Alarms</b>						
Thresholds	•	•	•	•	•	•
Load levels	•	•	•	•	•	•
System alarms	•	•	•	•	•	•
Protection alarms	•	•	•	•	•	•
Protection counters	•	•	•	•	•	•
Logical combination of alarms	•	•	•	•	•	•
<b>Trends</b>						
Average values	•	•	•	•	•	•
<b>Advanced functions</b>						
VirtualMonitor technology		•		•		•
AutoCorrect technology	•	•	•	•	•	•
Earth leakage monitoring	•	•	•	•	•	•
<b>Format</b>						
Pitch	18 mm	18 mm	19 mm	19 mm	25 mm	25 mm
Width	324 mm	324 mm	400 mm	400 mm	533.5 mm	533.5 mm



## Current sensors

	Solid-core current sensors							
								
	<b>TE-18</b>	<b>TE-25</b>	<b>TE-35</b>	<b>TE-45</b>	<b>TE-55</b>	<b>TE-90</b>		
Nominal current $I_n$ (A)		5 ... 20	25 ... 63	40 ... 160	63 ... 250	160 ... 630	400 ... 1000	600 ... 2000
Real range covered (A)		0.1 ... 24	0.5 ... 75.6	0.8 ... 192	1.26 ... 300	3.2 ... 756	8 ... 1200	12 ... 2400
Aperture (mm)		$\emptyset$ 8.4	$\emptyset$ 8.4	13.5 x 13.5	21 x 21	31 x 31	41 x 41	64 x 64
Dimensions (mm)		28 x 20 x 45	28 x 20 x 45	25 x 32.5 x 65	35 x 32.5 x 71	45 x 32.5 x 86	55 x 32.5 x 100	90 x 126 x 24.6
Connexion		RJ12	RJ12	RJ12	RJ12	RJ12	RJ12	RJ12

For currents above 1000 A, the 5A / RJ12 adaptor provides compatibility with CTs.

	Split-core current sensors				
					
	<b>TR/iTR-10</b>	<b>TR/iTR-14</b>	<b>TR/iTR-21</b>	<b>TR/iTR-32</b>	
Nominal current $I_n$ (A)		25 ... 63	40 ... 160	63 ... 250	160 ... 600
Real range covered (A)		0.5 ... 90	0.64 ... 120	1.26 ... 200	4 ... 720
Diameter (mm)		$\emptyset$ 10	$\emptyset$ 14	$\emptyset$ 21	$\emptyset$ 32
Dimensions (mm)		26 x 44 x 28	29 x 67 x 28	37 x 65 x 43	53 x 86 x 47
Connexion		RJ12	RJ12	RJ12	RJ12

For currents above 600 A, the 5A / RJ12 adaptor provides compatibility with CTs.

	Flexible current sensors						
							
	<b>TF-40</b>	<b>TF-80</b>	<b>TF-120</b>	<b>TF-200</b>	<b>TF-300</b>	<b>TF-600</b>	
Nominal current $I_n$ (A)		140 ... 400	150 ... 600	400 ... 2000	600 ... 4000	1600 ... 6000	1600 ... 6000
Real range covered (A)		2 ... 480	3 ... 720	8 ... 2400	12 ... 4800	32 ... 7200	32 ... 7200
Diameter (mm)		$\emptyset$ 40	$\emptyset$ 80	$\emptyset$ 120	$\emptyset$ 200	$\emptyset$ 300	$\emptyset$ 600
Connexion		RJ12	RJ12	RJ12	RJ12	RJ12	RJ12